


Kastar®

A Convenience of Life

HIGH
CAPACITY

Battery for
Camera & Camcorder

User Manual



www.mykastar.com

English

Battery Pack

Battery Pack is rechargeable battery pack intended for exclusive use with digital cameras & camcorders. Please fully charge the battery pack for your camera with the charger specified for it.



Safety Precautions

- Do not short-circuit the positive and negative terminals of the battery pack with metallic or other objects.
- Make sure you use the supplied battery case or you attach the terminal cover when transporting or storing the battery pack outside the camera.
- Avoid dropping or subjecting the battery pack to severe impacts.
- Do not attempt to disassemble or alter the battery pack.
- Do not apply heat or expose the battery pack to open flame. Further, do not apply water or liquid of any kind to the battery pack.
- Store the battery pack well out of the reach of children.

- If liquid leaks from the battery pack or it emits a strange odor, move it away from any sources of heat or fire immediately.

- Immediately flush water over parts of the body or clothing that come into contact with the inner contents of a battery if the outer casing incurs damage. If any of these substances should contact internal tissues, such as eyes or the mouth, immediately flush with water and seek medical assistance.

For product handling and usage, please refer to your digital camera & camcorder user manual.

Las baterías han sido diseñadas para utilizarse exclusivamente con cámaras digitales & camcorders. Cargue completamente la batería para su cámara con el cargador especificado para ella.

Precauciones de seguridad

- No conecte los terminales positivo y negativo con objetos metálicos ni de ningún otro tipo.
- Asegúrese de utilizar la caja de batería suministrada o colocar la tapa de los terminales cuando transporte o guarde la batería fuera de la cámara.
- Evite que la batería se caiga o que reciba golpes fuertes.
- No intente desarmar ni modificar la batería.
- No exponga la batería al calor ni al fuego. Además, no moje la batería con agua ni ningún otro tipo de líquido.
- Guarde la batería fuera del alcance de los niños.

• Si la batería tiene fugas de líquido o emite un olor extraño aléjela inmediatamente de las fuentes de calor o el fuego.

• Si el electrolito de la batería entra en contacto con su cuerpo lávese inmediatamente con agua corriente. Si el electrolito entrase en contacto con tejidos internos de su cuerpo, como los ojos o la boca, lávese con agua y solicite la ayuda de un médico.

Con respecto al manejo de esta cámara digital & camcorder, consulte el manual de instrucciones de la misma.

Contact Us

Help us Improve

Thanks for you purchasing from us. We would be happy to hear your opinion about the product. What is good. What can be better. Please share your thoughts. They will help us improve.

If you have any more inquiries or comments concerning our products, you can visit our website:

www.mykasear.com

Any problems

Please get in touch about any issues you're having, and we'll try our best to respond with 24 hours.

support@mykasear.com